MissSolar

User's Manual

Model no.: MS-7304

SOLAR SHED LIGHT

Energy Saving
Environmental Friendly

info@misssolar.com
made in China

LOCATION OF THE SOLAR LAMP

1) The solar lamp must be located in a position where it can get direct sunlight on the solar panel, and generally, free from cover and shade. (As shown in figure 1).

2) The Solar Shed Light need to be changed before use.

ASSEMBLY INSTRUCTIONS



A. Place the body of light indoor or outdoor where is dry and ventilation.
(1) Body of light 1 pc
(2) Solar Panel 1 pc

B. Place the solar panel under the sun where is free of the shade.
(1) Place solar panel southwards to ensure it to get sunshine in the whole day.
(2) Make the angle probably by adjusting the back support of the solar panel.
(3) Insert the plug of the solar panel into the socket on the light.
(4) To recharge the batteries, turn the switch to "OFF" position while not using the light.
(5) To use the light in the daytime, turn the switch to "ON" position while recharging at the same time.

C. Pull out the plug from the socket after the batteries are full charged in the daytime.
The light can be hanging on top or carrying by hand or placed upside down.

OPERATION

1) For daily/normal operation, move the switch to the AUTO position. The lamp will automatically turn ON during the night time.

2) The operating hours of the solar lamp during the night can vary from a few hours to throughout the night depending on the number of hours of sunlight received during the day.

REPLACING THE BATTERIES

There are 4 pcs 1500mAh Digital Rechargeable (Ni-MH) batteries inside the light. Generally, the life span of batteries is one year. They need to be replaced when the light looks very dim within 3 hours operating in the darkness after full sunny day charging, or after the batteries have been used for about one year or more. The methods of changing batteries are as followings:

1) Twist the light transparent cover by tuming it anticlockwise.
2) Open the battery box and replace the batteries with new ones.
3) Close the battery box and then fasten the lights transparent cover by tuming it clockwise.

TROUBLE SHOOTING

If your solar light does not turn ON at dusk, despite following to the above instructions, please check the following steps:

1) Ensure the solar Panel is not in the shade during the day.
2) Make sure the switch is in the "ON" position.
3) Check that the batteries are installed correctly.

MAINTENANCE

Clean the solar panel regularly with a damp cloth to guarantee optimum performance of the solar panel. If any deposit on the solar panel, please clean it with alcohol liquid softly (do not use any other type of solvents) Otherwise, the solar panel performance will be affected. Please also be careful not to apply too much pressure on the panel while cleaning.

Important Notice To Users

The operating hours of the solar lamp during the night depends on the solar charge received during the day.

On a bright sunny day, the solar lamp may operate for more than 8 hours during the night, whereas on a cloudy day, it may operate for a few hours only.During winter, and especially when there is hardly any sunshine, the solar lamp may not operate at all.

We recommend that the battery in the solar lamp be taken out for charging electrically by the NiMH (not RAM) charger for use during winter. When the lamp is not being used for more than a month, remove the battery and store them separately.

STORAGE: When the lamp is not being used for more than a month, remove the batteries and store them separately.